

Date : May 17, 2021

CERTIFICATE OF ANALYSIS – GC PROFILING

SAMPLE IDENTIFICATION

Internal code : 21E03-PTH05

Customer identification : Organic Tea Tree - Australia - T30115207R

Type : Essential oil

Source : *Melaleuca alternifolia* ct. Terpinen-4-ol (Tea Tree)

Customer : Plant Therapy

ANALYSIS

Method: PC-MAT-014  - Analysis of the composition of an essential oil or other volatile liquid by FAST GC-FID (in French); identifications validated by GC-MS.

Analyst : Seydou Ka, M. Sc.

Analysis date : May 13, 2021

Checked and approved by :

Sylvain Mercier, M. Sc., chimiste 2014-005

Notes: This report may not be published, including online, without the written consent from Laboratoire PhytoChemia. This report is digitally signed, it is only considered valid if the digital signature is intact. The results only describe the samples that were submitted to the assays.



PYHSICOCHEMICAL DATA

Physical aspect: Clear liquid

Refractive index: 1.4768 ± 0.0003 (20 °C; method PC-MAT-016)

ISO 4730:2017 - TEA TREE OIL

Compound	Min. %	Max. %	Observed %	Complies?
α-Pinene	1.0	4.0	2.1	Yes
Sabinene	tr	3.5	0.2	Yes
α-Terpinene	6.0	12.0	9.9	Yes
Limonene	0.5	1.5	0.9	Yes
para-Cymene	0.5	8.0	1.6	Yes
1,8-Cineole	tr	10.0	3.9	Yes
γ-Terpinene	14.0	28.0	20.3	Yes
Terpinolene	1.5	5.0	3.4	Yes
Terpinen-4-ol	35.0	48.0	44.8	Yes
α-Terpineol	2.0	5.0	3.1	Yes
Aromadendrene	0.2	3.0	0.4	Yes
Viridiflorene	0.1	3.0	0.4	Yes
δ-Cadinene	0.2	3.0	0.3	Yes
Globulol	tr	1.0	0.2	Yes
Viridiflorol	tr	1.0	0.1	Yes
Refractive index	1.4750	1.4820	1.4768	Yes

CONCLUSION

No adulterant, contaminant or diluent has been detected using this method.

ANALYSIS SUMMARY – CONSOLIDATED CONTENTS

New readers of similar reports are encouraged to read table footnotes at least once.

Identification	%	Class
Isobutyral	0.02	Aliphatic aldehyde
Isovaleral	tr	Aliphatic aldehyde
2-Methylbutyral	0.01	Aliphatic aldehyde
2-Methylbutyric acid	0.02	Aliphatic acid
(3Z)-Hexenol	0.08	Aliphatic alcohol
Hexanol	0.01	Aliphatic alcohol
α-Thujene	0.84	Monoterpene
α-Pinene	2.12	Monoterpene
Camphene	0.01	Monoterpene
Sabinene	0.18	Monoterpene
β-Pinene	0.69	Monoterpene
Myrcene	0.90	Monoterpene
Pseudolimonene	0.01	Monoterpene
α-Phellandrene	0.35	Monoterpene
Menthatriene isomer I	tr	Monoterpene
(3Z)-Hexenyl acetate	0.03	Aliphatic ester
α-Terpinene	9.93	Monoterpene
Carvomenthene	0.01	Aliphatic alcohol
ortho-Cymene	0.01	Monoterpene
para-Cymene	1.57	Monoterpene
Limonene	0.89	Monoterpene
1,8-Cineole	3.94	Monoterpenic ether
(Z)-β-Ocimene	tr	Monoterpene
(E)-β-Ocimene	0.02	Monoterpene
γ-Terpinene	20.28	Monoterpene
cis-Sabinene hydrate	0.04	Monoterpenic alcohol
Terpinolene	3.38	Monoterpene
para-Cymenene	0.01	Monoterpene
trans-Sabinene hydrate	0.06	Monoterpenic alcohol
Linalool	0.07	Monoterpenic alcohol
para-Mentha-1,3,8-triene	tr	Monoterpene
endo-Fenchol	0.01	Monoterpenic alcohol
cis-para-Menth-2-en-1-ol	0.36	Monoterpenic alcohol
4-Hydroxy-4-methylcyclohex-2-enone	0.01	Aliphatic alcohol
Cosmene isomer I	0.01	Monoterpene
Unknown	0.09	Oxygenated monoterpene
trans-para-Menth-2-en-1-ol	0.18	Monoterpenic alcohol
Unknown	0.01	Unknown
δ-Terpineol	0.02	Monoterpenic alcohol
Dill ether	0.01	Monoterpenic ether
Terpinen-4-ol	44.79	Monoterpenic alcohol
para-Cymen-8-ol	0.04	Monoterpenic alcohol
α-Terpineol	3.14	Monoterpenic alcohol
cis-Piperitol	0.09	Monoterpenic alcohol
trans-Piperitol	0.17	Monoterpenic alcohol

exo-2-Hydroxycineole	0.02	Monoterpenic alcohol
Nerol	0.03	Monoterpenic alcohol
Unknown	0.01	Oxygenated monoterpane
Piperitone	0.02	Monoterpenic ketone
Unknown	0.01	Unknown
cis-Carvenone oxide?	0.03	Monoterpenic ketone
trans-Ascaridole glycol	0.03	Monoterpenic alcohol
cis-Ascaridole glycol	0.02	Monoterpenic alcohol
Thymol	0.02	Monoterpenic alcohol
Carvacrol	0.01	Monoterpenic alcohol
Unknown	0.04	Monoterpenic alcohol
Bicycloelemene	0.02	Sesquiterpene
α-Cubebene	0.04	Sesquiterpene
Unknown	0.01	Unknown
Isoleldene	0.01	Sesquiterpene
α-Copaene	0.03	Sesquiterpene
7-Cubebene	0.04	Sesquiterpene
7-Cubebene epimer?	0.03	Aliphatic alcohol
β-Elemene	0.01	Sesquiterpene
α-Gurjunene	0.17	Sesquiterpene
β-Maaliene	0.01	Sesquiterpene
β-Caryophyllene	0.17	Sesquiterpene
β-Gurjunene	0.03	Sesquiterpene
α-Maaliene	0.01	Sesquiterpene
Aromadendrene	0.37	Sesquiterpene
Selina-5,11-diene	0.07	Sesquiterpene
Cadina-3,5-diene isomer I?	0.06	Sesquiterpene
trans-Muurola-3,5-diene	0.05	Sesquiterpene
α-Humulene	0.05	Sesquiterpene
Valeren-4,7(11)-diene	0.21	Sesquiterpene
trans-Cadina-1(6),4-diene	0.02	Sesquiterpene
γ-Muurolene	0.14	Sesquiterpene
Selina-4,11-diene	0.01	Sesquiterpene
β-Selinene	0.01	Sesquiterpene
allo-Aromadendr-9-ene	0.05	Sesquiterpene
δ-Selinene	0.05	Sesquiterpene
α-Selinene	0.03	Sesquiterpene
Bicyclogermacrene	0.47	Sesquiterpene
Viridiflorene	0.41	Sesquiterpene
α-Muurolene	0.08	Sesquiterpene
γ-Cadinene	0.03	Sesquiterpene
trans-Calamenene	0.03	Sesquiterpene
Zonarene	0.26	Sesquiterpene
δ-Cadinene	0.29	Sesquiterpene
trans-Cadina-1,4-diene	0.08	Sesquiterpene
α-Calacorene	0.01	Sesquiterpene
Unknown	0.05	Oxygenated sesquiterpene
Palustrol	0.03	Sesquiterpenic alcohol
Unknown	0.01	Oxygenated sesquiterpene
Eudesma-5,7(11)-diene	0.01	Sesquiterpene
Maaliol	0.02	Sesquiterpenic alcohol
Spathulenol	0.05	Sesquiterpenic alcohol

Laboratoire
PhytoChemia

Plus que des analyses... des conseils

Globulol	0.21	Sesquiterpenic alcohol
Gleenol	0.02	Sesquiterpenic alcohol
Viridiflorol	0.13	Sesquiterpenic alcohol
Cubeban-11-ol	0.08	Sesquiterpenic alcohol
Ledol	0.10	Sesquiterpenic alcohol
Rosifoliol	0.10	Sesquiterpenic alcohol
1-epi-Cubenol	0.12	Sesquiterpenic alcohol
Isopathulenol	0.04	Sesquiterpenic alcohol
Cubenol	0.07	Sesquiterpenic alcohol
α -Murolol	0.02	Sesquiterpenic alcohol
α -Cadinol	0.01	Sesquiterpenic alcohol
Consolidated total	99.10%	


tr: The compound has been detected below 0.005% of total signal.

Note: no correction factor was applied


About "consolidated" data: The table above presents the breakdown of the sample volatile constituents after applying an algorithm to collapse data acquired from the multi-columns system of PhytoChemia into a single set of consolidated contents. In case of discrepancies between columns, the algorithm is set to prioritize data from the most standard DB-5 column, and smallest values so as to avoid overestimating individual content. This process is semi-automatic. Advanced users are invited to consult the "Full analysis data" table after the chromatograms in this report to access the full untreated data and perform their own calculations if needed.

Unknowns: Unknown compounds' mass spectral data is presented in the "Full analysis data" table. The occurrence of unknown compounds is to be expected in many samples, and does not denote particular problems unless noted otherwise in the conclusion.

This page was intentionally left blank. The following pages present the complete data of the analysis.



DB-WAX



FULL ANALYSIS DATA

Identification	Column DB-5			Column DB-WAX		
	R.T	R.I	%	R.T	R.I	%
Isobutyral	0.40	530	0.02	0.46	778	0.02
Isovaleral	0.57	640	tr	0.70	883	tr
2-Methylbutyral	0.59	650	0.01	0.68	877	0.01
2-Methylbutyric acid	1.90	850	0.02			
(3Z)-Hexenol	1.98	856	0.08	5.57	1344	0.09
Hexanol	2.18	873	0.01	5.31	1326	0.01
α -Thujene	2.87	927	0.84	1.33	1000	0.84
α -Pinene	2.95	932	2.12	1.27	990	2.11
Camphepane	3.13	944	0.01	1.59	1026	0.01
Sabinene	3.55*	973	0.88	2.14	1082	0.18
β -Pinene	3.55*	973	[0.88]	1.97	1064	0.69
Myrcene	3.87	995	0.90	2.72	1132	0.90
Pseudolimonene	4.00*	1003	0.36	2.67	1128	0.01
α -Phellandrene	4.00*	1003	[0.36]	2.63	1124	0.35
Menthatriene isomer I	4.00*	1003	[0.36]	3.26	1175	tr
(3Z)-Hexenyl acetate	4.14	1012	0.03	4.64	1280	0.03
α -Terpinene	4.22*	1018	9.95	2.82	1140	9.93
Carvomenthene	4.22*	1018	[9.95]	2.32	1099	0.01
ortho-Cymene	4.27	1021	0.01	3.91*	1225	1.57
para-Cymene	4.32	1024	1.57	3.91*	1225	[1.57]
Limonene	4.38†	1027	4.85	3.02	1156	0.89
1,8-Cineole	4.41†	1030	[4.85]	3.14	1165	3.94
(Z)- β -Ocimene	4.60	1042	tr	3.68*	1208	20.28
(E)- β -Ocimene	4.77	1052	0.02	3.81	1217	0.02
γ -Terpinene	4.92	1062	20.28	3.68*	1208	[20.28]
cis-Sabinene hydrate	5.00	1066	0.04	6.69*	1427	0.06
Terpinolene	5.34*	1088	3.40	4.11	1240	3.38
para-Cymenene	5.34*	1088	[3.40]	6.15	1386	0.01
trans-Sabinene hydrate	5.47	1097	0.06	7.75	1506	0.06
Linalool	5.57	1103	0.07	7.85	1514	0.08
para-Menta-1,3,8-triene	5.62	1106	tr	5.90	1369	0.03
endo-Fenchol	5.68	1110	0.01	8.22*	1543	0.20
cis-para-Ment-2-en-1-ol	5.83	1120	0.36	7.90	1518	0.36
4-Hydroxy-4-methylcyclohex-2-enone	5.95	1127	0.01	13.79	2024	tr
Cosmene isomer I	6.02	1132	0.01	6.10	1383	0.03
Unknown [m/z 109, 43 (73), 71 (54), 124 (51), 69	6.12	1138	0.09			

(37), 41 (35)...152 (5)]					
<i>trans</i> -para-Menth-2-en-1-ol	6.15	1140	0.18	8.79	1588
Unknown [m/z 109, 124 (45), 119 (41), 43 (35), 91 (28), 95 (25)...]	6.25	1147	0.01	6.69*	1427
δ-Terpineol	6.56	1167	0.02	9.24	1624
Dill ether	6.80*	1182	44.80	7.11	1458
Terpinen-4-ol	6.80*	1182	[44.80]	8.42*	1559
para-Cymen-8-ol	6.86	1186	0.04	11.35	1801
α-Terpineol	6.95	1192	3.14	9.56	1650
cis-Piperitol	7.00	1195	0.09	9.37	1634
<i>trans</i> -Piperitol	7.19	1207	0.17	10.20*	1702
exo-2-Hydroxcineole	7.41	1222	0.02	11.40	1804
Nerol	7.53	1230	0.03	10.83	1756
Unknown [m/z 137, 152 (28), 43 (25), 91 (24), 109 (23), 119 (19)]	7.61	1236	0.01		
Piperitone	7.82	1250	0.02	9.71*	1662
Unknown [m/z 43, 82 (79), 109 (69), 110 (65), 95 (38), 41 (36)...]	7.88	1254	0.01		
<i>cis</i> -Carvenone oxide?	7.95	1258	0.03		
<i>trans</i> -Ascaridole glycol	8.07	1267	0.03	13.97	2042
<i>cis</i> -Ascaridole glycol	8.35	1285	0.02	14.54	2097
Thymol	8.58	1300	0.02	14.94	2137
Carvacrol	8.66	1306	0.01	15.10	2152
Unknown [m/z 97, 112 (92), 83 (62), 43 (44), 41 (25)... 170? (4)]	8.83	1318	0.04	14.80	2123
Bicycloelemene	9.08	1336	0.02	6.86	1440
α-Cubebene	9.27	1349	0.04	6.60	1420
Unknown [m/z 43, 95 (62), 107 (45), 110 (41), 55 (28), 67 (25)...]	9.38	1357	0.01	13.74*	2019
Isoleqdene	9.51	1366	0.01	6.69*	1427
α-Copaene	9.58	1371	0.03	6.93	1444
7-Cubebene	9.61	1374	0.04	6.96	1447
7-Cubebene epimer?	9.66	1377	0.03	7.06	1455
β-Elemene	9.82	1388	0.01	8.22*	1543
α-Gurjunene	10.06	1406	0.17	7.42	1482

β -Maaliene	10.11	1409	0.01	7.54	1490	0.02
β -Caryophyllene	10.18	1414	0.17	8.22*	1543	[0.20]
β -Gurjunene	10.30	1423	0.03	8.16	1538	0.02
α -Maaliene	10.35	1427	0.01	8.47	1562	0.02
Aromadendrene	10.45	1434	0.37	8.42*	1559	[45.25]
Selina-5,11-diene	10.47	1436	0.07	8.49	1564	0.07
Cadina-3,5-diene isomer I?	10.51	1439	0.06			
<i>trans</i> -Muurola-3,5-diene	10.61	1446	0.05	8.66	1578	0.06
α -Humulene	10.64	1448	0.05	9.06	1609	0.04
Valeren-4,7(11)-diene	10.73	1456	0.21	8.74	1584	0.29
<i>trans</i> -Cadina-1(6),4-diene	10.90	1468	0.02	9.03	1606	0.12
γ -Muurolene	10.94*	1471	0.15	9.43*	1639	0.47
Selina-4,11-diene	10.94*	1471	[0.15]	9.20	1621	0.01
β -Selinene	11.01	1476	0.01	9.64	1656	0.06
allo-Aromadendr-9-ene	11.07	1481	0.05	9.31	1630	0.13
δ -Selinene	11.14	1486	0.05	9.43*	1639	[0.47]
α -Selinene	11.22*	1492	0.92	9.71*	1662	[0.05]
Bicyclogermacrene	11.22*	1492	[0.92]	9.83*	1672	0.55
Viridiflorene	11.22*	1492	[0.92]	9.43*	1639	[0.47]
α -Muurolene	11.31	1498	0.08	9.83*	1672	[0.55]
γ -Cadinene	11.48	1511	0.03	10.14*	1697	0.29
<i>trans</i> -Calamenene	11.58	1520	0.03	10.99	1770	0.04
Zonarene	11.61*	1522	0.55	10.14*	1697	[0.29]
δ -Cadinene	11.61*	1522	[0.55]	10.20*	1702	[0.46]
<i>trans</i> -Cadina-1,4-diene	11.70	1529	0.08	10.43	1722	0.07
α -Calacorene	11.81	1538	0.01	11.86	1846	0.01
Unknown [m/z 161, 109 (98), 82 (93), 43 (72), 105 (68), 93 (59), 69 (56), 119 (55)... 222 (7)]	12.02	1554	0.05	13.05	1954	0.08
Palustrol	12.10*	1560	0.08	12.04	1862	0.03
Unknown [m/z 107, 163 (88), 59 (60), 93 (49), 43 (47), 81 (46... 204 (5)..]	12.10*	1560	[0.08]	12.96	1946	0.01
Eudesma-5,7(11)-diene	12.10*	1560	[0.08]	10.89	1761	0.01
Maaliol	12.10*	1560	[0.08]	12.82	1933	0.02
Spathulenol	12.24	1571	0.05	14.14	2058	0.04
Globulol	12.32	1578	0.21	13.66	2011	0.21
Gleenol	12.38	1583	0.02	13.34	1981	0.02
Viridiflorol	12.41*†	1585	0.21	13.74*	2019	[0.13]
Cubeban-11-ol	12.41*†	1585	[0.21]	13.44*	1991	0.15

Ledol	12.55	1596	0.10	13.12	1961	0.04
Rosifoliol	12.81	1617	0.10	14.07	2051	0.10
1-epi-Cubenol	12.89	1623	0.12	13.52	1998	0.12
Isospathulenol	13.00	1633	0.04	15.18	2161	0.04
Cubenol	13.06	1638	0.07	13.44*	1991	[0.15]
α -Murolol	13.11	1642	0.02	15.00	2143	tr
α -Cadinol	13.18	1647	0.01	15.29	2172	0.01
Total identified	98.91%			99.06%		
Total reported	99.14%			99.16%		

*: Two or more compounds are coeluting on this column

[xx]: Duplicate percentage due to coelutions, not taken into account in the consolidated total

t: Peaks apexes were resolved, but peaks overlapped and were summed for analysis

tr: The compound has been detected below 0.005% of total signal.

Note: no correction factor was applied

R.T.: Retention time (minutes)

R.I.: Retention index